



## Ocean Networks Canada September 2014 Dive Plans

<b>Dive Number:</b>	<b>OE0124</b>
<b>Date:</b>	<b>September 18 2014</b>
<b>Location:</b>	<b>Saanich Node Site</b>
<b>Launch Time:</b>	<b>0800</b>
<b>Recovery Time:</b>	<b>0845</b>
<b>Dive Coordinates:</b>	
<b>Saanich Node:</b>	<b>48° 39.0540' N, 123° 29.2030' W</b>
<b>Planned Saanich Inlet VIP:</b>	
<b>Submersible (ROV) Rigging Required for Dive:</b>	
Recovery Line (300m Blue Line with Sea Catch Hook) w/ Emergency Cutting Knife	
Seabird 19+ CTD w/ SBE43 Oxygen Sensor	
<b>Dive Operations Order and Procedures:</b>	
Deploy ROV	
Locate SI VIP	
Grab SI VIP ODI Hose and prepare hose for deployment	
Fly SI VIP ODI hose to Node	
Remove Dust Cap from SI Node Port NP2 and stow	
Plug SI VIP ODI Hose into SI Node Port NP2	
Recover ROV	
ROV On Deck	