



## Ocean Networks Canada September 2014 Dive Plans

<b>Dive Number:</b>	<b>OE0125</b>
<b>Date:</b>	<b>September 18 2014</b>
<b>Location:</b>	<b>Central Node Site</b>
<b>Launch Time:</b>	<b>1430</b>
<b>Recovery Time:</b>	<b>1600</b>
<b>Dive Coordinates:</b>	
<b>Central Node:</b>	<b>49° 2.4262' N, 123° 25.5477' W</b>
<b>Central VIP:</b>	<b>49° 2.4143' N, 123° 25.5826' W</b>
<b>Central VIP Tripod:</b>	<b>49° 2.4142' N, 123° 25.5775' W</b>
<b>Submersible (ROV) Rigging Required for Dive:</b>	
Recovery Line (450m Green Line with Sea Catch Hook) w/ Emergency Cutting Knife	
Seabird 19+ CTD w/ SBE43 Oxygen Sensor	
<b>Dive Operations Order and Procedures:</b>	
Deploy ROV	
Locate Node	
Disconnect VIP connector NP6; dust cap	
Fly connector back to the VIP	
Take bearing on VIP bullhorns	
Locate Vector tripod	
Take bearing on tripod	
Return tripod to VIP and hang	
Clip in recovery hook	
Recover ROV	
VIP on deck	